








Select "Type A" and press "Next"



Click "Install"








And then the cash drawer will open. Click "OK" to close pop-up window. There will be beeping alarm if the cash drawer is not closed in 10 seconds.





The message window will pop-up after the cash drawer is closed. Click “OK” to close the message window..