

Application Programming Guide

JavaPOS Driver

Ver. 1.01

AP3

Introduction

This manual provides information on the AP3 JavaPOS driver as well as on the usage POS printer products offered by AP3.

The following are terms contained in this manual.

- JDK : Java Development Kit
- JRE : Java Runtime Environment
- JavaPOS : Java Point of Sale
- JCL Utility : JavaPOS Configuration Loader Utility

[Reference Websites]

<http://www.javapos.com> : Java POS committee website

<http://java.com> : Official Java website

Table of Contents

1. Development environment	4
1-1 Communication Configuration	4
2. Property / Method	5
2-1 Property Range / Default Value	5
2-1-1 Capability property setting value.....	5
2-1-2 Property default value / Range	6
2-1-3 POSPrinter Method	6
2-1-4 POSPrinter Escape Sequences.....	7
2-1-5 Color bitmap printing support	7
3. Extended Functions	8
3-1 DirectIO Method / Commands Description	8
3-2 DirectIO Command	8
3-2-1 Direct Output	8
3-2-2 International character set setting.....	9
3-3 DirectIOEvent Event	9
4. Error Information	10
4-1 ResultCode List	10
4-1-1 Claim method	10
4-1-2 CheckHealth method	10
4-1-3 ClearOutput method	10
4-1-4 DirectIO method	11
4-1-5 PrintNormal method.....	11
4-1-6 PrintImmediate method	12
4-1-7 CutPaper method	12
4-1-8 RotatePrint method.....	13
4-1-9 PrintBitmap method.....	13
4-1-10 SetBitmap method.....	14
4-1-11 SetLogo method	14
4-1-12 TransactionPrint method.....	14
5. Precautions	15

1. Development environment

1-1 Communication Configuration

- Communication Configuration for serial interface
You will set communication configuration in JCL Utility.

Printer Model	Baud rate	Printer Type	etc
AP3	9600/19200/38400/57600/115200	Mono Thermal	180 dpi
AP3-3	9600/19200/38400/57600/115200	Mono Thermal	203 dpi

**Caution**

Check the default communication setting.
For more details refer to the user manual included in the printer package.

2. Property / Method

2-1 Property Range / Default Value

2-1-1 Capability property setting value

Capability property	AP3
CapCompareFirmwareVersion	FALSE
CapPowerReporting	TRUE
CapStatisticsReporting	FALSE
CapUpdateFirmware	FALSE
CapUpdateStatistics	FALSE
CapTransaction	TRUE
CapCoverSensor	TRUE
CapConcurrentRecSlp	FALSE
CapConcurrentJrnSlp	FALSE
CapConcurrentJrnRec	FALSE
CapCharacterSet	TRUE
CapRecUnderline	TRUE
CapRecPageMode	TRUE
CapCuncurrentPageMode	FALSE
CapRecStamp	FALSE
CapRecRotate180	TRUE
CapRecRight90	TRUE
CapRecPapercut	TRUE
CapRecNearEndSensor	FALSE
CapRecMarkFeed	FALSE
CapRecLeft90	TRUE
CapRecItalic	FALSE
CapRecEmptySensor	TRUE
CapRecDwideDhigh	TRUE
CapRecDwide	TRUE
CapRecDhigh	TRUE
CapRecColor	FALSE
CapRecCartridgeSensor	FALSE
CapRecBold	TRUE
CapRecBitmap	TRUE
CapRecBarCode	TRUE
CapRec2Color	FALSE
CapRecPresent	FALSE

2-1-2 Property default value / Range

1) List Property

Model	RecLineChars List	RecBarCode RotationList	FontTypeface List	RecBitmap List
AP3	"42,56"	""	""	0,L90,R90,180
AP3-3	"48,64"	""	""	0,L90,R90,180

- CharacterSetList Property

Model	Value
AP3 / AP3-3	437,1(Katakana),850,860,863,865,1252,866,852,858,862,864,23(Thai42),1253,1254,1257,27(Farsi),1251,737,775,31(Thai14),32(Hebrew Old),1255,34(Thai11),35(Thai18),855,857,928,39(Thai16),1256,1258,42(Khmer),1250,255

- Receipt Width and Height Property

Model	RecLineHeight	RecLineWidth	RecLinePaperCut
AP3	24	512	5
AP3-3	24	576	5

- RecLineSpacing Property

Property	Range		
	Default	Max	Min
RecLineSpacing	16	127	0

2-1-3 POSPrinter Method

Method	Value
beginInsertion	X
beginRemoval	X
changePrintSide	X
clearPrintArea	O
cutPaper	O
drawRuledLine	X
endInsertion	X
endRemoval	X
markFeed	X
pageModePrint	O
printBarCode	O
printBitmap	O
printImmediate	O
printMemoryBitmap	X
printNormal	O
printTwoNormal	X
rotatePrint	O
setBitmap	O
setLogo	O
transactionPrint	O
validateData	O

O: Supported X: Not supported

2-1-4 POSPrinter Escape Sequences

Escape Sequence	Value
[#]P	O (value range: 0~100)
[#]fP	O (value range: 0~100)
[#]sP	X
sL	X
[#]B	O (value range: 1~20)
tL	O
bL	O
[#]IF	O (value range: 0~9999)
[#]uF Base Pitch [inch]	O
[#]rF Maximum [inch]	X
#E	X
#R	X
#dL	X
#fT	O
[!]bC	O
[!][#]uC	O
[!]iC	X
[#]rC	O
[!]rvC	O
[#]sC	X
1C	O
2C	O
3C	O
4C	O
#hC	O
#vC	O
[#]fC	X
[!]tbC	X
[!]tpC	X
cA	O
rA	O
lA	O
[!][#]stC	X
N	O

O: Supported X: Not supported

2-1-5 Color bitmap printing support

- AP3 JavaPOS Driver supports following image formats.
- GIF, JPG, BMP Image Format.

3. Extended Functions

This section is to explain DirectIO method.
 This method will operate properly only with AP3 POS printer.

3-1 DirectIO Method / Commands Description

Argument	Explanation	Type
Command	Pre-define constant	Long
pData	Number of output data / Value defined by command	Long
pString	Output Data	String

Command	Constantvalue	Description
PTR_DI_OUTPUT	0	Output defined pString data
PTR_DI_INTERNATIONAL_CHAR	1	International character set define

3-2 DirectIO Command

3-2-1 Direct Output

Argument	Command	PTR_DI_OUTPUT
	pData	Null
	pString	Output data
Description	Sends data without any process after checking printer status. "pString" is not affected by "BinaryConversion"	
Return	Result Code	ResultCodeExtended
	JPOS_SUCCESS	0
	JPOS_E_CLOSED	0
	JPOS_E_CLAIMED	0
	JPOS_E_NOTCLAIMED	0
	JPOS_E_DISABLED	0
	JPOS_E_BUSY	0
	JPOS_E_ILLEGAL	0
	JPOS_E_OFFLINE	0
	JPOS_E_FAILURE	0

3-2-2 International charset setting

Argument	Command	PTR_DI_INTERNATIONAL_CHAR
	pData	pre-defined constant PRN_DI_CHAR_USA: 0 PRN_DI_CHAR_FRANCE: 1 PRN_DI_CHAR_GERMANY: 2 PRN_DI_CHAR_UK: 3 PRN_DI_CHAR_DENMARK1: 4 PRN_DI_CHAR_SWEDEN: 5 PRN_DI_CHAR_ITALY: 6 PRN_DI_CHAR_SPAIN1: 7 PRN_DI_CHAR_JAPAN: 8 PRN_DI_CHAR_NORWAY: 9 PRN_DI_CHAR_DENMARK2: 10
	pString	Null
Description	Sets International character set. If CharSet property value is changed, International character set will be reset.	
Return	Result Code	ResultCodeExtended
	JPOS_SUCCESS	0
	JPOS_E_CLOSED	0
	JPOS_E_CLAIMED	0
	JPOS_E_NOTCLAIMED	0
	JPOS_E_DISABLED	0
	JPOS_E_BUSY	0
	JPOS_E_ILLEGAL	0
	JPOS_E_OFFLINE	0
	JPOS_E_FAILURE	0

3-3 DirectIOEvent Event

- Not used.

4. Error Information

This section is to explain returned error information when use POSPrinter methods. For more details, please refer to the UPOS specifications.

4-1 ResultCode List

4-1-1 Claim method

Method	Result Code	ResultCodeExtended
Claim	JPOS_SUCCESS	0
	JPOS_E_ILLEGAL	JPOS_EPTR_UNRECOVERABLE
		JPOS_EPTR_MECHANICAL
		JPOS_EPTR_CUTTER
		JPOS_EPTR_OVERHEAT
		JPOS_EPTR_REC_EMPTY
	JPOS_EPTR_JRN_EMPTY	

4-1-2 CheckHealth method

Method	Result Code	ResultCodeExtended
CheckHealth	JPOS_SUCCESS	0
	JPOS_E_CLOSED	0
	JPOS_E_CLAIMED	0
	JPOS_E_DISABLED	0
	JPOS_E_ILLEGAL	0
	JPOS_E_OFFLINE	0
	JPOS_E_FAILURE	JPOS_EPTR_UNRECOVERABLE
		JPOS_EPTR_CUTTER
		JPOS_EPTR_MECHANICAL
		JPOS_EPTR_OVERHEAT

4-1-3 ClearOutput method

Method	Result Code	ResultCodeExtended
ClearOutput	JPOS_SUCCESS	0
	JPOS_E_CLOSED	0
	JPOS_E_CLAIMED	0
	JPOS_E_NOTCLAIMED	0

4-1-4 DirectIO method

Method	Result Code	ResultCodeExtended	
DirectIO	JPOS_SUCCESS	0	
	JPOS_E_CLOSED	0	
	JPOS_E_CLAIMED	0	
	JPOS_E_NOTCLAIMED	0	
	JPOS_E_DISABLED	0	
	JPOS_E_ILLEGAL	0	
	JPOS_E_OFFLINE	0	
	JPOS_E_FAILURE		JPOS_EPTR_UNRECOVERABLE
			JPOS_EPTR_CUTTER
			JPOS_EPTR_MECHANICAL
			JPOS_EPTR_OVERHEAT
	JPOS_E_EXTENDED		JPOS_EPTR_COVER_OPEN
			JPOS_EPTR_JRN_EMPTY
JPOS_EPTR_REC_EMPTY			

4-1-5 PrintNormal method

Method	Result Code	ResultCodeExtended	
PrintNormal	JPOS_SUCCESS	0	
	JPOS_E_CLOSED	0	
	JPOS_E_CLAIMED	0	
	JPOS_E_NOTCLAIMED	0	
	JPOS_E_DISABLED	0	
	JPOS_E_ILLEGAL	0	
	JPOS_E_OFFLINE	0	
	JPOS_E_FAILURE		JPOS_EPTR_UNRECOVERABLE
			JPOS_EPTR_CUTTER
			JPOS_EPTR_MECHANICAL
			JPOS_EPTR_OVERHEAT
	JPOS_E_EXTENDED		JPOS_EPTR_COVER_OPEN
			JPOS_EPTR_JRN_EMPTY
JPOS_EPTR_REC_EMPTY			

4-1-6 PrintImmediate method

Method	Result Code	ResultCodeExtended	
PrintImmediate	JPOS_SUCCESS	0	
	JPOS_E_CLOSED	0	
	JPOS_E_CLAIMED	0	
	JPOS_E_NOTCLAIMED	0	
	JPOS_E_DISABLED	0	
	JPOS_E_ILLEGAL	0	
	JPOS_E_OFFLINE	0	
	JPOS_E_FAILURE		JPOS_EPTR_UNRECOVERABLE
			JPOS_EPTR_CUTTER
			JPOS_EPTR_MECHANICAL
			JPOS_EPTR_OVERHEAT
	JPOS_E_EXTENDED		JPOS_EPTR_COVER_OPEN
			JPOS_EPTR_JRN_EMPTY
JPOS_EPTR_REC_EMPTY			

4-1-7 CutPaper method

Method	Result Code	ResultCodeExtended	
CutPaper	JPOS_SUCCESS	0	
	JPOS_E_CLOSED	0	
	JPOS_E_CLAIMED	0	
	JPOS_E_NOTCLAIMED	0	
	JPOS_E_DISABLED	0	
	JPOS_E_ILLEGAL	0	
	JPOS_E_OFFLINE	0	
	JPOS_E_FAILURE		JPOS_EPTR_UNRECOVERABLE
			JPOS_EPTR_CUTTER
			JPOS_EPTR_MECHANICAL
			JPOS_EPTR_OVERHEAT
	JPOS_E_EXTENDED		JPOS_EPTR_COVER_OPEN
			JPOS_EPTR_JRN_EMPTY
JPOS_EPTR_REC_EMPTY			

4-1-8 RotatePrint method

Method	Result Code	ResultCodeExtended	
RotatePrint	JPOS_SUCCESS	0	
	JPOS_E_CLOSED	0	
	JPOS_E_CLAIMED	0	
	JPOS_E_NOTCLAIMED	0	
	JPOS_E_DISABLED	0	
	JPOS_E_ILLEGAL	0	
	JPOS_E_OFFLINE	0	
	JPOS_E_FAILURE		JPOS_EPTR_UNRECOVERABLE
			JPOS_EPTR_CUTTER
			JPOS_EPTR_MECHANICAL
			JPOS_EPTR_OVERHEAT
	JPOS_E_EXTENDED		JPOS_EPTR_COVER_OPEN
			JPOS_EPTR_JRN_EMPTY
JPOS_EPTR_REC_EMPTY			

4-1-9 PrintBitmap method

Method	Result Code	ResultCodeExtended	
PrintBitmap	JPOS_SUCCESS	0	
	JPOS_E_CLOSED	0	
	JPOS_E_CLAIMED	0	
	JPOS_E_NOTCLAIMED	0	
	JPOS_E_DISABLED	0	
	JPOS_E_ILLEGAL	0	
	JPOS_E_OFFLINE	0	
	JPOS_E_FAILURE		JPOS_EPTR_UNRECOVERABLE
			JPOS_EPTR_CUTTER
			JPOS_EPTR_MECHANICAL
			JPOS_EPTR_OVERHEAT
	JPOS_E_NOEXIST		0
	JPOS_E_EXTENDED		JPOS_EPTR_COVER_OPEN
			JPOS_EPTR_JRN_EMPTY
			JPOS_EPTR_REC_EMPTY
			JPOS_EPTR_SLP_EMPTY
JPOS_EPTR_TOOBIG			
		JPOS_EPTR_BADFORMAT	

4-1-10 SetBitmap method

Method	Result Code	ResultCodeExtended	
SetBitmap	JPOS_SUCCESS	0	
	JPOS_E_CLOSED	0	
	JPOS_E_CLAIMED	0	
	JPOS_E_NOTCLAIMED	0	
	JPOS_E_DISABLED	0	
	JPOS_E_ILLEGAL	0	
	JPOS_E_OFFLINE	0	
	JPOS_E_FAILURE		JPOS_EPTR_UNRECOVERABLE
			JPOS_EPTR_CUTTER
			JPOS_EPTR_MECHANICAL
			JPOS_EPTR_OVERHEAT
	JPOS_E_NOEXIST		0
	JPOS_E_EXTENDED		JPOS_EPTR_COVER_OPEN
			JPOS_EPTR_JRN_EMPTY
			JPOS_EPTR_REC_EMPTY
JPOS_EPTR_SLP_EMPTY			
JPOS_EPTR_TOOBIG			
		JPOS_EPTR_BADFORMAT	

4-1-11 SetLogo method

Method	Result Code	ResultCodeExtended
SetLogo	JPOS_SUCCESS	0
	JPOS_E_CLOSED	0
	JPOS_E_CLAIMED	0
	JPOS_E_NOTCLAIMED	0
	JPOS_E_DISABLED	0
	JPOS_E_ILLEGAL	0

4-1-12 TransactionPrint method

Method	Result Code	ResultCodeExtended	
TransactionPrint	JPOS_SUCCESS	0	
	JPOS_E_CLOSED	0	
	JPOS_E_CLAIMED	0	
	JPOS_E_NOTCLAIMED	0	
	JPOS_E_DISABLED	0	
	JPOS_E_ILLEGAL	0	
	JPOS_E_OFFLINE	0	
	JPOS_E_FAILURE		JPOS_EPTR_UNRECOVERABLE
			JPOS_EPTR_CUTTER
			JPOS_EPTR_MECHANICAL
			JPOS_EPTR_OVERHEAT
	JPOS_E_EXTENDED		JPOS_EPTR_COVER_OPEN
			JPOS_EPTR_JRN_EMPTY
			JPOS_EPTR_REC_EMPTY
			JPOS_EPTR_SLP_EMPTY

5. Precautions

- 1) Reproduction of any part of this documentation by any means is prohibited.
- 2) The contents of this documentation are subject to change without notice.
- 3) Comments and notification of any mistakes in this documentation are gratefully accepted.
- 4) This software cannot be used with other equipment that the specified.
- 5) AP3 will not be responsible for any consequences resulting from the use of any information in this documentation.
- 6) AP3 JavaPOS driver is designed to operate properly with the latest firmware of each model. If the printer doesn't operate properly, please check the firmware version and contact the manufacturer.

Copyright

© Everint Co., Ltd. All rights reserved.

This user manual and all property of the product are protected under copyright law. It is strictly prohibited to copy, store, and transmit the whole or any part of the manual and any property of the product without the prior written approval of Everint Co., Ltd. The information contained herein is designed only for use with this Everint product. Everint is not responsible for any direct or indirect damages, arising from or related to use of this information.

- The Everint logo is the registered trademark of Everint Co., Ltd.
- All other brand or product names are trademarks of their respective companies or organizations.

Everint Co., Ltd. maintains ongoing efforts to enhance and upgrade the functions and quality of all our products.

In the following, product specifications and/or user manual content may be changed without prior notice.

Caution

Some semiconductor devices are easily damaged by static electricity. You should turn the printer "OFF", before you connect or remove the cables on the rear side, in order to guard the printer against the static electricity. If the printer is damaged by the static electricity, you should turn the printer "OFF".

