

NP1060 Disassembly Instructions

Remove the screw in the SSD cover and remove the SSD cradle.

Remove the 2 screws holding the MSR if installed or MSR blanking plate.

Remove the 4 screws holding on the stand.

Place the terminal face down on a soft surface.

Remove the 5 screws – Marked in red.

Using the included tool, push it into the seam at the location marked by the blue arrows. (starting on the side with the ports seems easiest)

Unclip each catch by pushing the tool toward the screen to lift the rear casing out and up away from the front.

You should hear a pop as it releases. (You may want to use a piece of cardboard or plastic to put in the gap to stop it closing up.)

Then move along to the next catch and repeat working your way around the case.

