

# NEXA ZED 2951 SCANNER

## Scan Mode

### Auto Sense Mode off

Decoding by pulling the trigger of the scanner when auto sense mode is off. It's default mode.



Off ( Default )

### Auto Sense Mode on

The scanner can sense barcode for decoding automatically.



On