

Desire POS

User Manual Point of Sale System



Office

14F-1, No.736, Jhongzheng Rd., Jhonghe
Dist., New Taipei City 235, Taiwan (R.O.C.)

Poslab.com.tw

Tel : + 886-2-7729-1900
Fax : + 886-2-7729-1901



Table of Contents

Chapter 1 Standard Package	3
Chapter 2 Touch Screen Driver Installation	4
Chapter 3 System View	7
Chapter 4 Accessories	8

Chapter 1 Standard Package

1.Desire



2.Power adaptor and cable



3.Drivers and User manual



Chapter 2 Touch Screen Driver Installation


2.1 Select the OS you are using.




2.2 In our case we select WINXP and double click the WINXP folder to open it. Then select SETUP.EXE and double click it to start the installation.




2.3 Click Next > to welcome window.




2.4 Click Next on the destination folder window.




2.5 Click next on the Start Menu Folder window.



2.6 Click Install on the Installation window.




2.7 Click Finish for the complete installation.



Chapter 3 System View

3.1 I/O ports



3.2 Power switch button Find your power button on your left hand side, behind LCD.



Chapter 4 Accessories

4.1 Card Reader



4.2 Customer Display, VFD Type

