

# WAVEPOS-55

## User Manual Point of Sale System



### Office

14F-1, No.736, Jhongzheng Rd., Jhonghe  
Dist., New Taipei City 235, Taiwan (R.O.C.)

### Poslab.com.tw

Tel : + 886-2-7729-1900  
Fax : + 886-2-7729-1901



# Table of Contents

Chapter 1 Standard Package	3
Chapter 2 Accessories	4
Chapter 3 Touch Screen Driver Installation	5
Chapter 4 System View	7
Chapter 5 Replace Hard Disk	8

# Chapter 1 Standard Package

## 1.WAVEPOS-55



## 2.Drivers and User manual



# Chapter 2 Accessories

## 2.1 Customer Display




## 2.2 Card Reader and i-Button




# Chapter 3 Touch Screen Driver Installation


3.1 Select SETUP.EXE and double click it to start the installation.




3.2 Click Next> to welcome window.



3.3 Click Next on the destination folder window.




3.4 Create the Icon Name and finished the installation.





# Chapter 4 System View

## 4.1 I/O ports



## 4.2 Power switch button

Find your power button on your left hand side.




# Chapter 5 Replace Hard Disk

5.1 Remove the 2 screws of Hard Disk drawer.



5.2 Drag the HDD drawer out.





### 5.3 Remove the SATA cable.

