

NEXA

BL-8040 Instructions for adding a ~ prefix (to suit QuickPos)

Please scan each barcode below starting from the top.

Enter/Exit Programming Mode




FULL ASCII code 39



Prefix



~



Save setting to confirm

Enter/Exit Programming Mode

